




THE NOMAD WEIGH

Professional Mobile Vehicle Weighing
0416794884 • www.thenomadweigh.com.au

WEIGHTS EXPLAINED





THE NOMAD WEIGH


Professional Mobile Vehicle Weighing
0416794884 • www.thenomadweigh.com.au

WEIGHTS EXPLAINED




Gross Combined Mass (GCM)

The combined weight of the towing vehicle (GVM) and any trailer (GTM) while coupled together.



Gross Vehicle Mass (GVM)


The weight transferred to the ground through the wheels of a fully loaded vehicle. Including the trailer tow ball weight (TBM) if towing.



Tow Ball Mass (TBM)

The weight imposed on the tow vehicle's tow hitch by the coupling of the trailer onto the tow bar.

Recommended to be 8 – 12% of ATM.



Gross Trailer Mass (GTM)

The weight transferred to the ground by the wheels of the trailer when coupled to a vehicle.



Aggregate Trailer Mass (ATM)

The weight of the loaded trailer (GTM) including the tow ball mass (TBM).